



DMX: PROFUSION iS

Your Profusion iS machine is loaded with your music and messaging profile. The player will automatically select the music and messaging as scheduled for each day.

The content consisting of both music and messaging is updated by CD or the internet, depending on your set up. On receiving an update disc, please insert it into the CD ROM drive found at the top of the player, the device will carry out the updated procedure automatically, ejecting the disc when complete. This process will not affect the music and/or messaging playing while updating.

Your DMX unit need not be turned off. Please leave running 24/7.

MESSAGING

Messaging can also be manually selected if need be:

1. Press the ★ star button and use the down arrow ↓ to select Message Control, press star again to select it
2. Use down arrow ↓ to select Message Playback and press ★ again to select it
3. Select your message with the arrows ↔ and press ★ to play
4. Music should resume once the message has played



SHUT DOWN PROCEDURE

Should the Profusion iS system stop playing, simply follow the Shut Down Procedure, disconnect the player from the wall socket, then re-start after 30 seconds.

STEP 1: Press the 'Standby' button once

STEP 2: This will put the machine into 'pause' mode. On the screen, you will see the following message 'Machine is now in pause mode, push the star to return to the music or Standby button to shut down'.

STEP 3: Press the star button and wait for the device to shut down

Should you require further assistance, please contact our Support Team 011 780 3000 | support@dmx.co.za